

**HL CANOPY LEG BUMPER INSTRUCTIONS**

<b>P/N 4110040 HL CANOPY LEG BUMPER PACKAGE (PAIR)</b>			
<b>Reference</b>	<b>Part Number</b>	<b>Quantity</b>	<b>Description</b>
	4100586	2	HL CANOPY LEG BUMPER
	<b>4100965</b>	<b>1</b>	<b>HL CANOPY LEG BUMPER BAG OF BOLTS</b> <i>consisting of:</i>
	5896248	8	3/8-16 x 6 CARRIAGE BOLT
	5896406	8	3/8 SAE FLAT WASHER
	5806243	8	3/8 SPLIT LOCK WASHER
	5896377	8	3/8-16 HEX NUT
	3603835	4	2-HOLE PLATE 2"

1. Read the following instructions thoroughly before starting work. If you don't understand a procedure, call Reimann & Georger Corporation or its distributors for assistance.
2. Insure that you have all the parts listed. If any parts are missing or damaged, return to place of purchase immediately.
3. Insert carriage bolts through face of the Canopy Leg Bumper. Two holes are located six inches from each end. The face of the bumper is counterbored to allow the head of the bolt to be recessed.
4. Mount the Canopy Leg Bumper to the rear Canopy Support Post. Align Two-Hole Plate with bolts on opposite surface of the Canopy Support Post. Clamp bumper in desired location flat washer, lock washer, and nuts.
5. Repeat steps 3 and 4 for the other bumper.