

## SAW CART PARTS LIST

Item Number	Part Number	Quantity	Description
1	2004815	1	CART FRAME
2	6400143	2	GRIP
3	2004816	1	WIRE ROPE ASSEMBLY
4	2004828	1	CLAMP
5	2004817	1	BRACKET PLATE
7	2004827	1	HANDLE TUBE
8	2004819	1	HANDLE
9	2004820	1	LIFTING ARM
11	2004829	2	WING NUT
13	2004823	1	SAW FRAME
14	2004824	1	SAW FRAME BRACKET
15	5806423	4	COTTER PIN
16	7606486	3	WHEEL
17	2004825	1	AXLE
18	5806418	1	ROLL PIN
19	2004826	1	HANDLE
20	6400654	1	GRIP
22	5806296	1	6 INCH BOLT
23	5806370	1	LOCKNUT

